

Trainings ▾

Specifications

Battery capacity (minimum recommended cold cranking amps): K38 Generator-Drive Ambient Temperature Above 10°C [50°F] Cold Cranking Amperes 1200 Ambient Temperature Above 0 to 10°C [32 to 50°F] Cold Cranking Amperes 1280 Ambient Temperature Above 0 to 32°C [-18 to 0°F] Cold Cranking Amperes 1800 K50 Generator-Drive Ambient Temperature Above 10°C [50°F] Cold Cranking Amperes 1280 Ambient Temperature Above 0 to 10°C [32 to 50°F] Cold Cranking Amperes 1800 Ambient Temperature Above 0 to 32°C [-18 to 0°F] Cold Cranking Amperes 1800 K38 and K50 Industrial Ambient Temperature Above -18°C [0°F] Cold Cranking Amperes 1800 K38 and K50 Marine Ambient Temperature Above -18°C [0°F] Cold Cranking Amperes 1800

Cold Cranking Amps ratings are based on two 12-VDC batteries in series.

Battery Cable Sizes - American Wire Gauge (maximum length in starting circuit): Number 00 6.1 m [20 ft] Number 000 8.2 meter [27 ft] Number 0000 or two Number 0 (see note) 10.7 meter [35 ft] Two Number 00 13.7 meter [45 ft]

Note : Two strands of number 0 cable can be used instead of one number 0000 cable, provided all connections are carefully made to maintain equal current flow in each parallel cable.

Reserve Capacity 640 minutes Minimum Cranking Speed Without Starting Aid 150 rpm Starting Circuit Resistance (maximum) 0.002 ohms

Batteries (Specific Gravity)

Battery State of Charge	Specific Gravity (at 27°C [80°F])
100 %	1.260 to 1.280
75%	1.230 to 1.250
50%	1.200 to 1.220
25%	1.170 to 1.190
DISCHARGED	1.110 to 1.130

