


Trainings ▾


General Information

The AFC (air-fuel control) tube allows intake manifold pressure to adjust the fuel metering. Therefore, if the engine is equipped with a turbocharger, the fuel pump meters more fuel for additional horsepower.



Remove


Remove the AFC tube.



Inspect for Reuse

Inspect the rubber sealing washers.

Replace as necessary.



Install

Use new copper washers for the banjo fitting.

Install the AFC tube.

Banjo Fitting	24 n.m	[18 ft-lb]
Threaded Fitting	8 n.m	[71 in-lb]

