


Trainings ▾

Measure

Measure the radial clearance of the shaft.

mm		in
0.30	MIN	0.012
0.46	MAX	0.018



The turbocharger **must** be removed for replaced if the clearances are out of specification. Refer to Procedure 010-033 (</qs3/pubsys2/xml/en/procedures/41/41-010-033-tr.html>).