

Trainings ▾

Engine Dataplate

Marine and Industrial Applications

The engine dataplates show specific information about your engine. The engine serial number and control parts list (CPL) provide information for ordering parts and service manuals.

Note : The engine dataplate must not be changed unless approved by Cummins.

The industrial engine dataplate is located on the top side of the gear housing. Have the following engine data available when communicating with a Cummins Authorized Repair Location. The information on the dataplate is **mandatory** when sourcing service parts.


©Cummins Inc

Cummins Engine Company, Inc. Columbus, Indiana 47202-3005 Assembled in U.S.A. Warnings: Injury can result and warranty is voided if fuel rate rpm or altitudes exceed published maximum values for this model and application. Date of MFG. 20010501 Assembled in U.S.A. 3284906	CID/L		CPL		Engine Serial No.		FEL	EPA
	Family				C/S		Nox	
					Engine Model		Pm	
	Valve lash		Inch	Int.	Exh	Timing -		
Cold		MM	Int.	Exh	Fuel rate at rated HP/KW mm3/st			
Firing Order				1 5 3 6 2 4		FR	Low idle RPM	
Gross Rated HP/KW						at RPM		


00800075

1. Control parts list (CPL)
2. Model
3. Engine serial number
4. Emissions certification
5. Horsepower and rpm rating.

Marine dataplate location.



Note : This marine diesel engine conforms to the NOx requirements of the International Maritime Organization (IMO), MARPOL 73/78, Annex VI, Regulation 3 as applicable.



Use the information from the marine engine dataplate when discussing service or the source of parts for your engine.

©Cummins Inc.

 Cummins Inc. Columbus, Indiana 47202-3005 Made in U.S.A.	Engine Cert. I.D.	C.I.D./ L 505 8.3	CPL 2172	Engine Serial No. 45983742	
Warnings: Injury may result and warranty is voided if fuel rate rpm or altitudes exceed published maximum values for this model and application.	Timing-TDC	Family	4		
	Value lash cold	Cust. Spec.	5		
	Firing order	Rated HP (Metric)	6		
Date of Mfg.	Low Idle (rpm)	E.C.S.	Fuel rated at HP	7	
20000508	600		196 mm 3 stroke		
3393177			Model Name	8	
			6CTA8.3-MS		

00900311

1. Cubic inch displacement and liter displacement
2. Control Parts List Number
3. Engine serial number
4. Emission family identification
5. Customer specification - base engine part number
6. Rated horsepower at rpm
7. Fuel rated at horsepower
8. Model name
9. Emission control system (currently **not** used on marine)
10. Firing order
11. Valve lash cold
12. Timing - top dead center
13. Low idle (rpm)
14. Date of manufacturing
15. Warning tag
16. Cummins address:
17. Cummins Incorporated
18. Columbus, Indiana

19. 47202-3005

20. Made in U.S.A.


21. Engine certification identification (currently **not** used on marine).

Cummins® Engine Nomenclature

Marine Applications

6CTA8.3M2 Marine Applications


- 6 = number of cylinders
- C = engine series
- T = turbocharged
- A = aftercooled
- 8.3 = displacement in liters
- M = marine
- 3 = design phase



Industrial Applications


6CTAA8.3 Industrial Applications

- 8.3 = displacement in liters
- AA = charge air aftercooled
- T = turbocharged
- C = engine series
- 6 = number of cylinders




Fuel Injection Pump Dataplate

The Bosch® fuel injection pump dataplate is located on the side of the injection pump. It provides information for fuel pump calibration.



The Cummins part number for the fuel pump-governor combination is located on the governor dataplate.



ECM Dataplate

The external ECM dataplate is located on top of the ECM.

The dataplate contains the ECM part number (P/N), the ECM serial number (S/N), the manufacturing date code (D/C), the engine serial number (ESN), and the ECM code.

