



Trainings ▾

Engine Views



Cylinder Block


1. Coolant inlet
2. Water pump impeller
3. Coolant flow to oil cooler
4. Coolant flow past oil cooler
5. Upper coolant manifold
6. Coolant flow to cylinder head.



08900200

Cylinder Head


1. Flow from upper coolant manifold
2. Flow to liner cavity
3. Cylinder head gasket
4. Coolant flow orifice.



08900200

Cylinder Block


1. Flow past cylinder liners
2. Lower coolant manifold.



08900202

Thermostat

1. Thermostats
2. Flow to water pump inlet
3. Bypass passage open
4. Flow from lower coolant manifold
5. Partial coolant flow to radiator
6. Restricted flow to bypass
7. Flow to radiator
8. Bypass closed.




10900282

Sea Water Aftercooled

1. From thermostat (coolant outlet)
2. To water pump (coolant inlet)
3. Heat exchanger

4. Sea water from pump
5. Sea water outlet (in exhaust)
6. Coolant from exhaust manifold to block
7. Turbocharger exhaust housing
8. Exhaust manifold
9. Coolant from block.

©Cummins Inc



10500209

Sea Water Aftercooled

1. Turbocharger air to aftercooler
2. Sea water inlet
3. Sea water strainer
4. Sea water pump
5. Cooled air to intake manifold
6. Sea water from aftercooler to gear cooler
7. Sea water from gear cooler to heat exchanger.