

Trainings ▾

Maintenance Check

Note : The G-Drive fuel lift pump inlet screen, or prefilter, filters fuel before it enters the lift pump. The prefilter consists of a filter head with glass bowl and plastic strainer. The glass bowl can be removed by means of a thumbscrew when it is necessary to clean the prefilter.

Perform a check of the prefilter daily for water and debris.

Remove the strainer and clean with compressed air or replace every 6 months or 250 hours, or at the oil change interval.

Clean the strainer more frequently if required.

