


## Trainings ▾

### Fill

Fill the makeup tank with oil.



Check the fault code indicator lamp. If the lamp is flashing, contact your Cummins Authorized Repair Facility.

