

Trainings ▾

Specifications

Minimum Recommend ed Battery Capacity					
Engine Model	Temperature Range	System Voltage	Cold Cranking Ampere	Ampere Hours	Reserve Capacity
QST30	-18° to 0°C	24 VDC	1800	400	640
	[0° to 32°F]				

The number of plates within a given battery size determines the reserve capacity. Reserve capacity is the length of time in which sustained cranking can occur.

Cold cranking amperes are based on two 12-VDC batteries in series.

Listed below are battery cable sizes in American wire gauge (maximum length in cranking motor circuit).

24 to 32 VDC

Number 00 6.1 m [20 ft]Number 000 8.2 m [27 ft]Number 0000 or two number 0* 10.7 m [35 ft]Two number 00 13.7 m [45 ft]

Minimum cranking speed without starting aid	150 rpm
---	---------

*Two strands of number 0 cable can be used in place of one number 0000 cable providing all connections are carefully made so that equal current flow is in each parallel cable.

Batteries (Specific Gravity)

Specific Gravity at 27°C [80°F]	State of Charge
1.260 to 1.280	100 %
1.230 to 1.250	75 %
1.200 to 1.220	50 %

Specific Gravity at 27°C [80°F]	State of Charge
1.170 to 1.190	25 %
1.110 to 1.130	Discharged