

## Fault Code: 1357

### Engine Oil Level Remote Reservoir - Data Valid But Below Normal Operating Range - Moderately Severe Level

 Printable Version

#### Overview

| Codes                                                                                | Reason                                                               | Effect                                        |
|--------------------------------------------------------------------------------------|----------------------------------------------------------------------|-----------------------------------------------|
| Fault Code: 1357<br><br>PID(P): P17<br>SPN: 1380<br>FMI: 1/18<br>Lamp: Amber<br>SRT: | The remote engine oil reservoir is below the normal operating level. | Possible damage to engine if left unresolved. |



Engine Oil Remote Reservoir Level Sensor Circuit

#### Circuit Description

The engine oil remote reservoir level sensor is used to monitor the oil level inside the remote reservoir.

#### Component Location

The engine oil remote reservoir level sensor is located in the engine oil remote reservoir and the location is OEM dependent.

## Conditions For Running The Diagnostics

This diagnostic runs continuously when the generator set controller is active.

## Conditions For Setting The Fault Codes

The Engine Control Module (ECM) detected the remote reservoir engine oil level was low.

## Action Taken When The Fault Code Is Active

- The generator set controller displays a warning fault immediately when the diagnostics runs and fails.

## Conditions For Clearing The Fault Code

- To validate the repair, start the engine and let it run for 1 minute at no load.
- The generator set controller will turn off the warning indicator immediately after the user presses reset.
- The “Reset All Faults” command in the recommended Cummins® electronic service tool or equivalent can be used to clear active faults.

## Shoptalk

Possible causes of this fault code include:

- Low engine oil level in the remote reservoir
- Malfunctioning engine oil remote reservoir level sensor.
- Malfunctioning or damaged OEM wiring harness.

Refer to Troubleshooting Fault Code 1357 . (</qs3/pubsys2/xml/en/procedures/60/60-t05-1357.html>)