

Fuel Rack Actuator Driver Mechanically Stuck Closed - Data Valid But Below Normal Operating Range - Moderately Severe Level

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check for active fault codes.	
	STEP 1A. Read the fault codes.	Fault Code 173 active
STEP 2.	Clear the fault codes.	
	STEP 2A. Disable the fault code.	Fault Code 173 inactive?
	STEP 2B. Clear the inactive fault codes.	All fault codes cleared?

STEP 1. Check for active fault codes.

STEP 1A. Read the fault codes.

Conditions :

- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Read the fault codes. • Use INSITE™ electronic service tool to read the fault codes.	Fault Code 173 active? YES	Go to Fault Code 173.
	Fault Code 173 active? NO Repair : Replace the fuel pump. Refer to Procedure 005-012 in Section 5 (/qs3/pubsys2/xml/en/procedures/57/57-005-012.html) (Fuel Injection Pumps, In-Line) in the QST30 Service Manual, Bulletin 4021539.	2A

STEP 2. Clear the fault codes.

STEP 2A. Disable the fault code.

Conditions : • Connect all components. • Turn keyswitch ON. • Connect the INSITE™ electronic service tool.		
Action	Specification/Repair	Next Step
Disable fault code. • Start the engine and let it idle for 1 minute. • Use INSITE™ electronic service tool to verify that the fault code is inactive.	Fault Code 173 inactive? YES	2B
	Fault Code 173 inactive? NO Repair : Verify that all steps have been completed. If all steps have been completed, then follow the technical escalation process.	Escalate or call for assistance.

STEP 2B. Clear the inactive fault codes.

Conditions :

- Connect all components.
- Turn keyswitch ON.
- Connect the INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
Clear the inactive fault codes. • Use INSITE™ electronic service tool to clear the inactive fault codes.	All fault codes cleared? YES	Repair complete.
	All fault codes cleared? NO Repair : Troubleshoot any remaining active fault codes.	Go to the appropriate troubleshooting charts.