

Reset

Reset with Mechanically Actuated Injectors

- For CENSE™ CM530 modules **only**, the data **must** be reset every 250 hours in order to maintain maximum memory capacity.
 1. First retrieve the CENSE™ data that has been saved.
 2. Select the fault codes and trend data options for resetting.
- Contact a Cummins® Authorized Repair Location for detailed instructions.



Reset with Electronically Actuated Injectors

- These engines do **not** use CENSE™. Instead they have Advanced Engine Monitoring built into the electronic control modules. This data does **not** need to be reset because it will automatically write over the oldest data in case the memory capacity becomes full. However, this memory can be cleared manually using INSITE™ electronic service tool. Fault logs need to be viewed even if they are **not** going to be reset.

Note : The CENSE™ CM2330 modules do **not** need to be reset.