


Trainings ▾

ECM Dataplate

The external electronic control module (ECM) dataplate is located on the front of the ECM.

The dataplate contains the ECM part number (P/N), the ECM serial number (S/N), the manufacturing date code (D/C), the engine serial number (ESN), and the ECM code.

©Cummins Inc.



17c00046