


Fault Code: 141

Engine Oil Pressure/Temperature Sensor Circuit

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 141 PID(P): P100 SPN: 100 FMI: 4/4 Lamp: Yellow SRT:	Low voltage detected at the oil pressure circuit.	No engine protection for oil pressure.



Oil Pressure Sensor Circuit

Circuit Description

The oil pressure/temperature sensor is used by the electronic control module (ECM) to monitor the lubricating oil pressure. The ECM monitors the voltage on the signal pin and converts this to a pressure value. The oil pressure value is used by the ECM for the engine protection system.

Component Location

The oil pressure/temperature sensor is located on the engine block to the left of the fuel filter, behind the air compressor.

Shoptalk

If Fault Code 143 or 415 is present, the problem is probably base engine related.

Refer to Troubleshooting Fault Code t05-141 (</qs3/pubsys2/xml/en/procedures/82/82-t05-141.html>)

Last Modified: 07-Aug-2015
