


Fault Code: 199

ICON™ Lamp

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 199 PID(P): S122, 4 SPN: 612 FMI: 4 Lamp: Yellow SRT:	Less than 6 VDC (low voltage) detected at the ICON™ lamp circuit when high voltage was expected by the ECM.	The ICON™ system will be disabled. Only mandatory shutdown will be enabled.



ICON™ Lamp Circuit

Circuit Description

The ICON™ lamp circuit illuminates the ICON™ lamp to indicate when the ICON™ system is active. In addition, ICON™ active fault codes will be flashed out on this lamp. The lamp circuit requires a specific flash timing (on/off timing). If the on/off voltage is incorrect, ICON™ will be disabled. The lamp circuit **must** be functional to enable ICON™.

Component Location

The ICON™ lamp is located in the vehicle cab on the dash panel.

Shoptalk

This fault indicates a short circuit to ground or an open circuit.

Refer to Troubleshooting Fault Code t05-199 (</qs3/pubsys2/xml/en/procedures/82/82-t05-199.html>)

Last Modified: 02-Sep-2010
