


Fault Code: 222

Ambient Air Pressure Sensor Circuit

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 222 PID(P): P108 SPN: 108 FMI: 4/4 Lamp: Yellow SRT:	Low voltage detected at the ambient air pressure circuit.	Derate in power output of engine.



Ambient Air Pressure Sensor Circuit

Circuit Description

The ambient air pressure sensor monitors atmospheric pressure and passes information to the electronic control module (ECM) through the sensor harness.

Component Location

The ambient air pressure sensor is located below the ECM.

Shoptalk

Monitor the ambient air pressure reading with a service tool to confirm that the pressure reading matches the actual air pressure.

Refer to Troubleshooting Fault Code t05-222 (</qs3/pubsys2/xml/en/procedures/82/82-t05-222.html>)

Last Modified: 02-Sep-2010
