

Trainings ▾

ECM Dataplate

The external electronic control module (ECM) dataplate is located on the front of the ECM.

The dataplate contains the ECM part number, the ECM serial number, the manufacturing date code, the engine serial number, and the ECM code.

