


Trainings ▾

Engine Views


©Cummins Inc



00a00073

Front View


1. Crossover tube
2. Lubricating oil filter
3. Coolant temperature sensor
4. Vibration damper.



00a00074

Left Bank


1. Intake manifold pressure sensor
2. OEM harness 21-pin and 31-pin connectors
3. Intake manifold temperature sensor
4. Engine position sensor
5. Oil pressure sensor
6. Fuel injection pump
7. Fuel shutoff valve (EHAB).



00a00075

Right Bank

1. Intake manifold temperature sensor
2. Intake manifold pressure sensor
3. Secondary ECM
4. Fuel injection pump
5. Fuel shutoff valve (EHAB)
6. Engine speed sensor.



00a00076

Rear View

1. Deutsch 23-pin connector (primary/secondary ECM connector)
2. Engine speed sensor
3. Flywheel
4. Engine position sensor.