

Trainings ▾

Maintenance Check

Centinel tank oil level should be checked daily to ensure that there is enough oil to operate the engine. Some tanks may be OEM supplied, refer to the OEM manufacturer's instructions for checking oil level in those installations. It is critical that engine oil level in the engine sump be checked daily even when using a makeup tank. Refer to procedure 007-043. Centinel™ is prohibited on engines with an aftertreatment system.

