


Trainings ▾

Inspect

Remove the fuse protective covers from the fuse(s) that are being checked. Check to make sure the fuse is installed in the fuse holder correctly.



If the fuse is installed correctly, check for a blown fuse.

Remove the fuse(s) to be checked.

Touch each one of the multimeter leads to each fuse terminal. Measure the resistance.

The multimeter **must** show less than 10 ohms, which is a closed circuit. If the circuit is closed then put the fuse back into the holder and connect the fuse cover.

