

Trainings ▾

General Information

The symbols are used **only** in printed manuals to help communicate the intent of the instructions. Symbols will **not** appear in the online version of this procedure. When one of the symbols appears in the printed manual, the symbol conveys the meaning defined below.

Four symbols are possible for each text and graphic combination.

WARNING

©Cummins Inc.

Serious personal injury or extensive property damage can result if the warning instructions are not followed.

CAUTION

©Cummins Inc.

Minor personal injury can result or a part, and assembly, or the engine can be damaged if the caution instructions are not followed.

Indicates a **REMOVAL** or **Dissassembly** step.

©Cummins Inc.

Indicates an **INSTALLATION** or **ASSEMBLY** step.

INSPECTION is required.

CLEAN the part or assembly.

PERFORM a mechanical or time **MEASUREMENT**.

LUBRICATE the part or assembly.

Indicates that a **WRENCH** or **TOOL SIZE** will be given.

TIGHTEN to a specific torque.

PERFORM an electrical **MEASUREMENT**.

Refer to another location in this manual or another publication for additional information.

The component weighs 23kg [50 lb] or more. To reduce the possibility of personal injury, use a hoist or get assistance to lift the component.

