

Trainings ▾

Remove


Front Gear Train

For front gear train engines, the closed crankcase ventilation valve is located between the tappet cover breather and intake manifold/cover of the engine.

The tappet cover closed crankcase ventilation valve is held in place by the molded closed crankcase ventilation hoses.

Note : Disconnecting and removing the hoses will also remove the valve.

Disconnect and remove the molded closed crankcase ventilation hoses and crankcase ventilation valve.



Rear Gear Train

For rear gear train engines, the closed crankcase ventilation valve is connected between the flywheel housing and intake manifold/cover of the engine.

The tappet cover closed crankcase ventilation valve is held in place by the molded closed crankcase ventilation hoses.

Note : Disconnecting and removing the hoses will also remove the valve.

Disconnect and remove the molded closed crankcase ventilation hoses and crankcase ventilation valve.

