


Trainings ▾

Remove

Front Gear Train


Remove the two capscrews retaining the filter head.

Remove the filter head from the engine.



Rear Gear Train

Remove the three capscrews holding the fuel filter bracket to the cylinder block.



Disassemble

Remove the dual-filter adapter, if equipped.

