

Trainings ▾


Tool Number

3824591

Engine Barring Gear

Used to engage the flywheel ring gear to rotate the crankshaft.

©Cummins Inc




Tool Number

3822509

Injector Bore Brush

Used to clean carbon from injector bores. For cylinder heads with 2 valves per cylinder.

©Cummins Inc




3822509

Tool Number

3822510

Injector Bore Brush

Used to clean the injector bore in the cylinder head. For cylinder heads with 4 valves per cylinder.




3822510

Tool Number

3823921

Capscrew Length Gauge

Used to measure the length of the cylinder head capscrews. For cylinder heads with 2 valves per cylinder.



3823921


Tool Number

3164057

Capscrew Length Gauge

Used to measure the length of the cylinder head capscrews. For cylinder heads with 4 valves per cylinder.

©Cummins Inc



22d00085

Tool Number

3375182

Valve Spring Tester

Used to check spring tension.

©Cummins Inc

3375182




Tool Number

3164438

Depth Gauge Assembly

Used to measure liner protrusion, injector protrusion, cylinder block counterbore depths, and valve intrusion and/or protrusion. Equipped with electronic digital indicator.

©Cummins Inc



3164438


Tool Number

3823258

Abrasive Pad

Used to clean carbon from the upper liner bores, for removing rust and corrosion, and for scuffing surfaces.

©Cummins Inc



22900039


Tool Number

3164055

Valve Stem Seal Installer

Used to install the valve stem seal.

©Cummins Inc



22d00088


Tool Number

3163293

Boot Plier

Used to remove the valve seal.

©Cummins Inc



3163294


Tool Number

3164329 and 3163292

Valve Spring Compressor

3164329 can be used to compress the all four valve springs at once for one cylinder on engines with 4 valves per cylinder. 3163292 can be used to compress both valve springs at once for one cylinder on engines with 2 valves per cylinder.

©Cummins Inc



3162986


Tool Number

3375960

Valve Spring Compressor

Used with cylinder head removed. Quickly removes springs using shop air.

©Cummins Inc



22d00238


Tool Number

4918219

Precision Straightedge

Used to check cylinder head combustion deck for flatness.

©Cummins Inc



22d00222

Tool Number

3165170

Valve Seat Extractor Collet

Used with slide hammer, Part Number 3376617. Slide Hammer sold separately. For cylinder heads with 4 valves per cylinder.

©Cummins Inc

**3376146**


Tool Number

3165171

Valve Seat Installer

Used for installing valve seats. For cylinder heads with 4 valves per cylinder.

©Cummins Inc



22d00234


Tool Number

3165182

Valve Guide Arbor

Use with Seat Cutter ST-257 to cut valve seat pockets for oversize seats. Can also be used with Gauge ST-685-4 to check valve seat concentricity. For cylinder heads with 4 valves per cylinder.

©Cummins Inc



22d00235


Tool Number

3376405

Valve Seat Grooving Tool

Cuts groove in valve seat. This is often required prior to use of valve seat extractor. Requires cutter bit Part Number 3376407. Cutter Bit is sold separately.

©Gummine Inc




Tool Number

3165183

Valve Seat Cutters

3165183 = .010 Oversize, 3165184 = .020 Oversize. Used with Valve Seat Cutter ST-257. For cylinder heads with 4 valves per cylinder.

©Cummins Inc



22d00236


Tool Number

ST-257

Valve Seat Cutter

Used to cut valve seat pockets for oversize seats. Valve Guide Arbor Part Number 3165182 and cutter bit Part Number 3165183 or Part Number 3165184 also required.

©Cummins Inc




22d00237

Tool Number

3375432

Crack Detection Kit (dye type)

©Cummins Inc



22d00239

