


Trainings ▾


General Information

Follow the Normal Starting Procedures in this section in cold weather. The Wait-To-Start lamp will stay on longer.



⚠ WARNING ⚠

Do not use starting fluids with this engine. This engine is equipped with an intake air heater: use of starting fluid can cause an explosion, fire, personal injury, severe damage to the engine and property damage.



The **only** recommended cold weather starting aids for marine applications are engine coolant pre-heaters and oil pan immersion heaters.

Cold weather starting aids are available for your engine. Contact a local Cummins Authorized Repair Location for more information.