


Trainings ▾

General Information

Cummins® Inboard Joystick system is now offered with equipment manufacturer (OEM) supplied thruster systems. There are two different versions of lever control stations and inboard joysticks. The legacy lever control station version is all versions 3 and older and the existing version is 4 and greater. The legacy joystick version is all versions 2 and older and the existing version is 3 and greater. Version 3 and greater joysticks and version 4 and greater lever control stations will come pre-configured from factory with Handle ID Number 1. Existing and legacy joysticks and lever control stations are backwards compatible.




Cummins® Inboard Joystick System

Cummins® Electronic Throttle and Shift and Cummins® Inboard Joystick basic component locations.

1. Lever Control Station on main helm
2. Inboard Joystick on main helm
3. Throttle Control Processor Module near engine
4. Thruster Interface Module
5. Bow Thruster
6. Stern Thruster.

Cummins® Inboard Joystick with OEM-Supplied Thruster Systems

Cummins® Electronic Throttle and Shift and Cummins® Inboard Joystick basic component locations with harnesses.




1. Lever Control Station on main helm
2. Inboard Joystick on main helm
3. Throttle Control Processor Module near engine
4. Thruster Interface Module (Switch, Analog, or CAN-based)
5. OEM-Supplies Bow Thruster
6. OEM-Supplied Bow Thruster.

Cummins® Inboard Joystick System

Cummins® Electronic Throttle and Shift (ETS) and Cummins® Inboard Joystick basic component locations with harnesses.


1. Lever Control Station on main helm
2. Inboard Joystick on main helm
3. Throttle Control Processor Module near engine
4. Thruster Interface Module
5. Bow Thruster
6. Stern Thruster
7. Port Engine
8. Starboard Engine
9. Throttle Control Processor Module Interface Harness
10. Controller Area Network (CAN) Data Extension Harness
11. Controller Area Network (CAN) Data Harness Tee
12. Thruster Interface Data Harness with tool port
13. Thruster Interface Thruster Harness
14. Thruster Extension Harness.



Cummins® Inboard Joystick System with OEM-Supplied Thruster Systems

Cummins® Electronic Throttle and Shift (ETS) and Cummins® Inboard Joystick with OEM-Supplied Thruster System with harnesses.


1. Lever Control Station on main helm
2. Thruster Control Panel on main helm
3. Throttle Control Processor Module near engine
4. Thruster Interface Module (Switch, Analog, or CAN-based)
5. OEM-Supplied Bow Thruster
6. OEM-Supplied Stern Thruster
7. Port Engine
8. Starboard Engine
9. Throttle Control Processor Module Interface Harness
10. Controller Area Network (CAN) Data Extension Harness
11. Controller Area Network (CAN) Data Harness Tee
12. Thruster Interface Data Harness with tool port and dual relay module
13. Thruster Interface Thruster Harness
14. Thruster Extension Harness.



Cummins® Electronic Throttle and Shift (ETS) and Thruster Control Panel basic component locations with harnesses,

1. Lever Control Station on main helm
2. Thruster Control Panel on main helm

3. Throttle Control Processor Module near engine
4. Thruster Extension Harness
5. Bow Thruster
6. Stern Thruster
7. Port Engine
8. Starboard Engine
9. Throttle Control Processor Module Interface Harness
10. Controller Area Network (CAN) Data Extension Harness.



Last Modified: 09-Sep-2019
