

Trainings ▾

Cooling System

Tool Number

CC-2602

Cooling System Test Kit

The Fleetguard® coolant test kit is used to check the concentration of coolant additives in the cooling system.

©Cummins Inc



Test Strip Bottle



Small Plastic Container



Syringe


Tool Number

CC-2800

Refractometer

The Fleetguard® refractometer is used to measure the freezing point protection and antifreeze concentration.

©Cummins Inc



ra8toda


Tool Number

ST-647

Standard Puller

Use to remove the stamped steel water pump pulley. Use in conjunction with two capscrews 5/16 x 18 x 2.

©Cummins Inc



ad8toga


Tool Number

ST-1225

Thermostat Seal Mandrel

Use to install the thermostat seal in the thermostat housing.

©Cummins Inc



th2togb


Tool Number

ST-1293

Belt Tension Gauge

Use to measure the fan drive v-ribbed belt tension.

©Cummins Inc



fa8togc

Tool Number

3376326

Pulley Installation Tool

Used to install drive pulleys. Use in conjunction with Part Number 3377401 adapter.

©Cummins Inc



ad8togb


Tool Number

3377462

Digital Optical Tachometer

Used to measure rpm of a viscous fan.

©Cummins Inc



3377462,


Tool Number

3376488

Guide Pin

Two guide pins are used to install the water heater plate.

©Cummins Inc



ci8toga


Tool Number

3822985

Combustion Gas Leak Test Kit

Includes: Part No. 3822986, test fluid; Part No. 3822987, adapter; and Part No. 3877612, instructions.

©Gummine Inc



3822985


Tool Number

3822994

Coolant Pressure/Temperature/Flow Analyzer Kit

Includes: Part Number 3822995 pressure gauge; Part Number 3822996, temperature gauge; Part Number 3822997, flow sight glass, Part Number 3822998 Compuchek™ fitting (Female); and Part Number 3377613, instructions. Optional: Part Number 3823099, hose extension kit, is also available.

©Cummins Inc



3822994


Tool Number

3824117

Bearing Installation Tool

Used to replace the water pump drive needle bearing in the gear housing.

©Cummins Inc



3824117


Tool Number

3823815

Water Pump Seal Driver

Used to install the unitized seal in the water pump. For use on engines with EGR. For use with Chicago-Allis™ seal. The seal is identified by the Cummins® part number only.

©Cummins Inc



22200124


Tool Number

4918797

Water Pump Seal Driver

Used to install the unitized seal in the water pump. For use on engines with EGR. For use with Kaco™ seals. The seal is identified by the Kaco™ name.

©Cummins Inc



22200124