

Trainings ▾


Tool Number

ST-1325

Dial Gauge Attachment

Attaches to crankshaft flange to provide measuring of flywheel and flywheel housing runout with dial bore gauge.

©Cummins Inc



fh8togb


Tool Number

3376050

Dial Indicator and Sleeve Assembly

Use with Part Number ST-1325 dial gauge attachment, to measure flywheel and flywheel housing runout.

©Cummins Inc


**Tool Number**

3824926

Guide Pin Kit

Aid during removal and installation of flywheel and flywheel housing.

©Cummins Inc




Tool Number

3823709

Idler Shaft Puller and Capscrew

Used to remove the idler shaft from the idler gear and flywheel housing on engines equipped with a REPTO flywheel housing.

©Cummins Inc




Tool Number

3824927

Cup Plug Driver

Used to install the cup plug in a REPTO flywheel housing. Requires a cup plug driver handle.

©Cummins Inc



3824927

Tool Number

3824928

Offset Wrench

Used to loosen or tighten four hidden mounting capscrews on engines equipped with a REPTO flywheel housing.

©Cummins Inc

**3823711**

Last Modified: 27-Aug-2002
