


Trainings ▾

Engine Views

The following illustrations contain information about engine components, filter locations, drain points, and access locations for instrumentation and engine controls. The information and configuration of components shown in these illustrations are of a general nature. Some component locations will vary, depending on applications and installations.

Industrial and Generator Drive

©Cummins Inc




01200141

Left - QSM11 Industrial and Generator Drive

1. ECM cooling plate
2. ECM
3. Compressor air inlet
4. Blowby measurement
5. Ambient air pressure sensor
6. Fuel return to tank
7. Engine dataplate
8. Engine serial number
9. Starter
10. Flywheel ring gear speed sensor
11. Side oil drain
12. Centinel™ (optional)
13. Fuel inlet to pump

14. Fuel filter
15. Rail pressure
16. Power steering pump mounting location
17. Oil pressure and temperature sensor
18. Engine position sensor
19. Freon compressor mounting location.
20. Compressor air discharge (not visible).

©Cummins Inc



01200109

Right - QSM11 Industrial and Generator Drive

1. Ether hookup
2. Before charge air cooler
3. Boost temperature sensor
4. Intake manifold pressure sensor
5. After charge air cooler (intake manifold)
6. Shutter stat
7. Engine vent coolant
8. Shutter stat
9. Fan sensor
10. Coolant temperature sensor
11. Heater return
12. Coolant inlet pressure
13. Makeup line from radiator
14. Water pump pressure
15. Coolant inlet
16. Oil drain
17. Oil pan pump heater
18. Filter outlet pressure
19. Engine brake oil supply
20. Filter inlet pressure
21. Block coolant pressure

- 22. Coolant heater
- 23. Heater supply
- 24. Coolant temperature pickup
- 25. Wastegate controller.

Last Modified: 12-Nov-2014
