

## Trainings ▾

### General Information

Most of the maintenance operations described in this manual can be performed with common hand tools, metric and SAE wrenches, sockets, and screwdrivers.

The following is a list of special service tools required for some of the maintenance operations:

| Tool Part Number: | Description:                                                           |
|-------------------|------------------------------------------------------------------------|
| 3400157           | Oil filter wrench                                                      |
| 3376592           | Torque wrench (valve and injector adjustment)                          |
| 3163196           | Torque wrench adapter (used with 3376592 torque wrench)                |
| 3400158           | Engine coolant and fuel filter wrench                                  |
| 3822524           | Belt tension gauge, click type (v-belts and v-ribbed with 4 or 5 ribs) |
| 3822525           | Belt tension gauge, click type (v-ribbed with 6 to 12 ribs)            |
| ST-1138           | Belt tension gauge (v-belts)                                           |
| ST-537            | Dial depth gauge                                                       |
| 3164019           | Chip removal tool                                                      |
| ST-1293           | Belt tension gauge (v-ribbed belts)                                    |
| CC-2800           | Refractometer                                                          |
| CC-2602           | Coolant test kit                                                       |

Contact a Cummins® Authorized Repair Location for the required service tools.