





Trainings ▾

Flow Diagram

Automotive with CM570



1. Coolant inlet
2. Coolant flow from coolant filter
3. Coolant bypass flow from thermostat
4. Coolant flow to water pump
5. Coolant flow from water pump
6. Coolant flow past oil cooler
7. Coolant flow to cylinder head.




00c00042

Dual Thermostat

1. Coolant flow from cylinder block to cylinder head
2. Coolant flow from cylinder head to thermostat housing
3. Coolant flow to radiator
4. Coolant bypass passage
5. Coolant bypass flow to water pump
6. Coolant bypass closed
7. Thermostats.


Automotive with CM870



08c00124

1. Coolant inlet
2. Coolant flow from coolant filter
3. Coolant bypass flow from thermostat
4. Coolant flow to water pump
5. Coolant flow from water pump

6. Coolant flow past oil cooler
7. Coolant flow to cylinder head.
8. Lubricating oil cooler
9. Coolant supply to EGR valve body
10. Coolant flow around EGR valve
11. EGR valve coolant return to thermostat housing
12. EGR cooler coolant supply from cylinder block
13. Coolant flow through EGR cooler
14. EGR cooler coolant return to thermostat housing
15. Thermostat housing
16. Coolant supply to turbocharger
17. Coolant return from turbocharger.



Single Thermostat

1. Coolant flow through cylinder head
2. Coolant flow from cylinder head to thermostat housing
3. Thermostat
4. Bypass open
5. Coolant flow through thermostat housing to bypass passage
6. Coolant bypass passage
7. Coolant bypass flow to water pump
8. Coolant flow to water pump
9. Bypass closed
10. Coolant flow to radiator
11. Coolant flow from radiator.

