



Trainings ▾

Flow Diagram




Electric Drive Crankcase Ventilation System - Normal Operations

1. Inlet (from gear housing)
2. Breather motor
3. Oil drain
4. Outlet (to turbocharger compressor inlet connection)
5. Closed Crankcase Ventilation (CCV) system pressure sensor
6. Oil drain.



Air Drive Crankcase Ventilation System - High Load

1. Inlet (from rocker lever housing)
2. Boost air tube
3. Crankcase breather
4. Outlet (to turbocharger compressor inlet connection)
5. Oil drain
6. CCV system pressure sensor
7. Oil drain
8. Oil supply line.



Air Drive Crankcase Ventilation System - Low Load

1. Inlet (from rocker lever housing)
2. Crankcase breather
3. Outlet (to the bypass tube)
4. Bypass tube (to air intake manifold)

5. Oil drain.

Last Modified: 25-Nov-2024
