


Fault Code: 253

Oil Level - Engine Protection

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 253 PID(P): P98 SPN: 098 FMI: 1 Lamp: Engine Protection SRT:	Low oil level has been detected. Voltage signal on the oil level signal pin 12 of the engine harness indicates low oil level in the engine.	Calibration-dependent progressive power derate and engine shutdown with increasing time after alert.



Oil Level Sensor

Circuit Description

The oil level sensor is used by the ECM to monitor the amount of oil in the engine. Low oil level detected at pin 12 can cause the engine **not** to start.

Component Location

The oil level sensor is located in the oil pan on the left side of the engine.

Refer to Troubleshooting Fault Code t05-253 (/qs3/pubsys2/xml/en/procedures/19/19-t05-253.html)

Last Modified: 01-Mar-2011
