


Fault Code: 471

Very Low Oil Level - Engine Protection

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 471 PID(P): S98 SPN: 098 FMI: 1/17 Lamp: Maintenance SRT: QU-471	Very Low Oil Level - Engine Protection. Very low oil level is detected. Voltage signal on the oil level signal pin 12 of the engine harness indicates very low oil level in the engine.	Calibration-dependent progressive power derate and engine shutdown with increasing time after alert. Centinel™ feature is disabled.



Oil Level Sensor Circuit

Circuit Description

The oil level sensor is used by the engine control module (ECM) to monitor the amount of oil in the engine.

Component Location

The oil level sensor is located in the oil pan on the left side of the engine.

Refer to Troubleshooting Fault Code t05-471. (/qs3/pubsys2/xml/en/procedures/19/19-t05-471.html)

Last Modified: 27-Oct-2015
