


Fault Code: 498

Oil Level Sensor Circuit

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 498 PID(P): SPN: FMI: Lamp: Warning SRT:	Engine oil level #1 sensor circuit - shorted high.	No engine protection for low oil level. Centinel system is disabled.



Oil Level Sensor Circuit

Circuit Description

The oil level sensor is used by the electronic control module (ECM) to monitor the lubricating oil level. The ECM monitors the voltage on the oil level signal pin and converts this to an electronic value. The oil level value is used by the ECM for the engine protection system.

Component Location

Refer to the Engine Diagrams in Section E of this manual for the component location.

Shoptalk

High voltage can be caused by the signal wire shorting to another wire in the harness, an open circuit in the return wire, or a faulty sensor.

Refer to Troubleshooting Fault Code t05-498 (</qs3/pubsys2/xml/en/procedures/19/19-t05-498.html>)

Last Modified: 01-Mar-2011
