

Control Panel Configured Incorrectly

Symptoms

- The control panel is configured incorrectly for the engine application.

How To Use This Tree

This symptom tree can be used to troubleshoot a malfunction. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

This fault code has no external wiring from the control panel except the +24 VDC control panel power supply.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the customer interface box (C.I.B.) wiring.	
	STEP 1A. Check the control panel display for faults.	Control panel indicates fault(s)?
	STEP 1A-1. Check the control panel power SUPPLY wire for voltage +24 VDC.	Less than +24 VDC?

STEP 1. Check the customer interface box (C.I.B.) wiring.

STEP 1A. Check the control panel display for faults.

Conditions :

- Locate the control panel display.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the control panel display for faults.	Control panel indicates fault(s)? YES Repair : Troubleshoot the appropriate fault code. Reference the Marine Auxiliary QSB7-DM CM850 Fault Code Troubleshooting Manual, Bulletin 4325972, Section TF; or ISM and QSM 11 Electronic Control System Troubleshooting and Repair Manual, Bulletin 3666266, Section TF; or X15 CM2350 X125M Fault Code Troubleshooting Manual, Bulletin 5504346, Section TF.	Repair complete
	Control panel indicates fault(s)? NO	1A-1

STEP 1A-1. Check the control panel power SUPPLY wire for voltage +24 VDC.

Conditions :

- Open the C.I.B.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the voltage at the battery 1 voltage (switched power) wire at the control panel. - Place one test lead at the battery 1 voltage (switched power) SUPPLY wire at the control panel. - Place the other test lead on the panel ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than +24 VDC? YES Repair : Check the batteries. See equipment manufacturer service information.	Repair complete
	Less than +24 VDC? NO	Contact a Cummins® Authorized Repair Location.