

Trainings ▾

Install

Install the fan hub, clutch, and capscrews. Tighten the capscrews alternately and evenly.

Torque Value: 47 n•m [35 ft-lb]

