

## Trainings ▾

### Install

#### Rear Gear Train

##### **⚠ CAUTION ⚠**

**Care must be taken when installing the gasket. Do not twist or stretch it. Failure to do so can result in an oil leak.**

Install the rocker housing and a new rocker housing gasket, if removed.

**Torque Value:** 24 n•m [ 212 in-lb ]

