

## Trainings ▾

### General Information

©Cummins Inc.

**Note :** Due to the number of water inlet connection options, the following procedure has been commonized. The illustrations may **not** match the engine being serviced, but the procedures are the same.

### Remove

Remove the capscrews, water inlet connection, gasket, and rectangular sealing ring.

