

Trainings ▾

Compressed Air System


Tool Number

3164330

B3.9 and B5.9 Engines Piston Ring Compressor

Used to compress all piston rings to permit easy installation of piston and rod assemblies.

©Cummins Inc



3164330


Tool Number

3375072

Dial Bore Gauge

Used to measure the cylinder bores.

©Cummins Inc



oi8togu


Tool Number

3375182

Valve Spring Tester

Used to check spring tension.

©Cummins Inc




Tool Number

3376399

O-ring Pick

Used to remove and install o-rings.

©Cummins Inc



3376399


Tool Number

3376663

Coupling Puller

Used to remove the spline coupling hub.

©Cummins Inc



3376663


Tool Number

3377415

Air Compressor Seat Installation Tool

Used to install the exhaust valve seats.

©Cummins Inc



3377415


Tool Number

3377416

Air Compressor Seat Removal Tool

Used to remove the exhaust valve seats.

©Cummins Inc



3377416


Tool Number

3823528

Air Compressor Seat Socket

Used to remove the exhaust valve seat and the inlet valve cage.

©Cummins Inc

**3823528**


Tool Number

3823597

Mounting Plate

Used to mount the air compressor to the vise.

©Cummins Inc



Tool Number

3823923

Spacer

Used with coupling puller, Cummins Part Number 3376663, to remove the hydraulic pump drive coupling.

©Cummins Inc



3823923


Tool Number

3824591

Barring Tool

Used to engage the flywheel ring gear to rotate the crankshaft.

©Cummins Inc



3824591


Tool Number

4918294

B4.5 and B4.5 RGT Engines Piston Ring Compressor

Used to compress all piston rings to permit easy installation of piston and rod assemblies.

©Cummins Inc



4918294


Tool Number

ST-1143

Air Compressor Bushing Mandrel

Used to remove and install the crankshaft bushing in the crankcase and the support.

©Cummins Inc



st-1143


Tool Number

ST-302

Ball Joint Vise

Used to hold the air compressor for disassembly or assembly.

©Cummins Inc




Tool Number

ST-647

Standard Puller

Used to pull the drive gear. Use with puller capscrews that have M8 x 1.25-6H threads.

©Cummins Inc



ad8toga

Last Modified: 12-Dec-2019
