


Trainings ▾


General Information

Marine Applications


©Cummins Inc



1. Coolant inlet
2. Water pump impeller
3. Coolant flow past oil cooler
4. Coolant flow through block cavity
5. Coolant to cylinder head.



1. Coolant flow from the cylinder block
2. Coolant to the thermostat housing
3. Coolant flow past injector
4. Thermostat
5. Coolant bypass passage
6. Coolant flow to pump inlet
7. Bypass closed
8. Coolant flow back to radiator.




Jacket Water Aftercooled

1. Thermostat housing
2. Coolant outlet
3. Heat exchanger

4. Coolant return to water pump
5. Water pump
6. Coolant supply from cylinder head to turbocharger
7. Water cooled turbocharger
8. Water cooled exhaust manifold
9. Coolant outlet from exhaust manifold
10. Expansion tank
11. Exhaust manifold vent line
12. Cylinder head vent line
13. Coolant supply to aftercooler
14. Aftercooler coolant return to cylinder head.


©Cummins Inc



08900210

Sea Water Aftercooled – Sea water Flow

1. Seawater supply
2. Seawater pump
3. Fuel cooler
4. Aftercooler zinc anode
5. Aftercooler housing
6. Aftercooler element
7. Transmission gear oil cooler
8. Heat exchanger
9. Exhaust outlet
10. Seawater return.



08900311

Sea water Aftercooled — Engine Coolant Flow

1. Thermostat housing
2. Coolant outlet
3. Heat exchanger
4. Coolant return to water pump
5. Water pump
6. Coolant supply from cylinder block to turbocharger
7. Water cooled turbocharger
8. Water cooled exhaust manifold
9. Coolant outlet from exhaust manifold
10. Expansion tank
11. Exhaust manifold vent line
12. Cylinder head vent line.