


Trainings ▾

General Information



1. Air In
2. Air Out
3. Coolant In
4. Coolant Out
5. Lubricating Oil In
6. Lubricating Oil Out Is Internal to the Gear Housing.