

Display Software Will Not Install and/or Update

Symptoms

- Display software will **not** download into the display.
- Display shows a red screen while downloading.

How To Use This Tree

This symptom tree can be used to troubleshoot display software download issues. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

- Possible causes include:
- Incompatible USB stick
 - USB stick **not** plugged in properly
 - Software corrupted.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check USB stick and port.	
	STEP 1A. Software file download.	Software file download?
	STEP 1B. Check the USB stick installation.	USB stick installed properly?
	STEP 1C. Check USB stick compatibility.	USB stick compatible?
STEP 2.	Check the display software.	
	STEP 2A. Check the display software.	Display software compatible?
	STEP 2B. Download display software into another ED-4 display.	Display software downloaded properly?

STEPS		SPECIFICATIONS
	STEP 2C. Download display software into another USB stick.	Display software downloaded properly?

STEP 1. Check USB stick and port.

STEP 1A. Software file download.

Conditions :

- Turn enable switch OFF.
- Turn enable switch ON.

Action	Specification/Repair	Next Step
Check USB stick and port. • Attempt to download the software file to the ED-4 display. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Software file download? YES Repair : The download of the software file has corrected the issue.	Repair complete.
	Software file download? NO	1B

STEP 1B. Check the USB stick installation.

Conditions :

- None.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the USB stick installation. Verify the USB stick is installed in the display USB port properly. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html) If a Cummins® USB extension harness is not being used, verify USB connection. Some USB connectors are reversible.	USB stick installed properly? YES	1C
	USB stick installed properly? NO Repair : Install USB stick properly. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Repair complete.

STEP 1C. Check USB stick compatibility.

Conditions : None.		
Action	Specification/Repair	Next Step
Check USB stick compatibility. Verify the USB stick is compatible with the display. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	USB stick compatible? YES	2A
	USB stick compatible? NO Repair : Download the display software to a compatible USB stick. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Repair complete.

STEP 2. Check the display software.

STEP 2A. Check the display software.

Conditions :

- Turn enable switch ON.

Action	Specification/Repair	Next Step
Check display software. Verify the display software on USB stick meets download requirements. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Display software compatible? YES	2B
	Display software compatible? NO Repair : Re-download the latest version of the display software from Cummins® QuickServe® On-line webpage to the USB stick. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Repair complete.

STEP 2B. Download the display software into another ED-4 display.

Conditions :

- Turn enable switch ON.

Action	Specification/Repair	Next Step
Download the display software. Download the latest display software to another ED-4 display. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Display software download properly? YES Repair : The download of the display software has corrected the issue.	Repair complete.
	Display software download properly? NO	2C

STEP 2C. Download the display software into another USB stick.

Conditions :

- Turn enable ON.

Action	Specification/Repair	Next Step
Download the display software. Download the display software into another USB stick. Re-attempt to download software to malfunctioning ED-4 display.	Display software downloaded properly? YES Repair : The download of the display software has corrected the issue.	Repair complete.
	Display software downloaded properly? NO Repair : Replace the ED-4 display. Refer to Procedure 015-035 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-035.html)	Repair complete.