

Traffic on CAN1 Higher Than Expected

Symptoms

- Alarm Code 7416 is displayed.

How To Use This Tree

This symptom tree can be used to troubleshoot controller area network (CAN) symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

- Possible causes include:
- Original equipment manufacturer (OEM) device on network
 - ED-4 source address.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the ED-4 display	
	STEP 1A. Check ED-4 software.	Latest vessel personality file and software installed?
	STEP 1B. Check configuration in ED-4 setup.	ED-4 displays setup correctly?
	STEP 1C. Check the OEM device.	Alarm Code 7416 active?

STEP 1. Check the ED-4 display.

STEP 1A. Check ED-4 software.

Conditions :		
Turn system enable switch ON.		
Action	Specification/Repair	Next Step

• Verify latest VPF is downloaded in the display. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) • Verify the latest display software is downloaded in the ED-4 display. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Latest vessel personality file and software installed? YES	1B
	Latest vessel personality file and software installed? NO Repair : Download correct VPF to the display from Cummins QuickServe® Online. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) Download latest version of the display software from Cummins QuickServe® Online. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Repair complete.

STEP 1B. Check configuration in ED-4 setup.

Conditions :

- Turn system enable switch ON.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

• Wait 30 seconds. • Read the ED-4 display.	Alarm Code 7416 active? YES Repair : Refer to the Display Does Not Display Data - J1939 Does Not Work troubleshooting tree in Section TT.	Repair complete.
	Alarm Code 7416 active? NO Repair : Verify the OEM device source address is setup incorrectly. See equipment manufacturer service information.	Repair complete.