


Trainings ▾

Remove

Remove the five front crankshaft seal mounting capscrews.



Remove and discard the front crankshaft seal from the front gear cover with the Front and Rear Crankshaft Seal Installation and Removal Tool Kit, Part Number 3163349.

