

Trainings ▾


Tool Number

3163196

Torque Wrench Adapter

Use to secure the rocker lever adjusting screw while tightening the locknut.

©Cummins Inc




Tool Number

3375784

Light Duty Puller

Use to remove small bushings, oil seals, and bearings.

©Cummins Inc

**3375784**

Tool Number

3376592

Torque Wrench

Use this Inch-pound torque wrench to tighten the valve lever adjusting screw. This torque wrench does not require a screwdriver attachment.




Tool Number

3162458

Rocker Lever Bushing Mandrel

Use to install and/or remove rocker lever bushings.

©Cummins Inc



03400049


Tool Number

3375432

Crack Detection Kit

Use to inspect the housing for cracks.

©Cummins Inc



3375432


Tool Number

3823557

Feeler Gauge Set

Used to set valves.

©Cummins Inc



22400189