



Trainings ▾

Flow Diagram

©Cummins Inc




1. Lubricating oil pan
2. Lubricating oil suction tube
3. Lubricating oil pump
4. Lubricating oil pressure regulator valve
5. Lubricating oil coolers
6. Lubricating oil cooler thermostat (open)
7. Lubricating oil cooler thermostat (closed).




07400271

1. Lubricating oil flow from oil coolers
2. Lubricating oil flow to filters
3. Lubricating oil filter bypass valve(s)
4. Lubricating oil filter(s)
5. Lubricating oil from filters
6. Main lubricating oil rifle
7. Lubricating oil flow to cylinder head
8. Lubricating oil flow to rear idler gear
9. Normal lubricating oil flow through filter
10. Bypass lubricating oil flow.




07400270

1. Lubricating oil flow from filters
2. Main lubricating oil rifle
3. Lubricating oil drilling to turbocharger supply
4. Lubricating oil drilling to piston cooling nozzle oil rifle
5. Lubricating oil flow to camshaft bushings and cylinder head
6. Lubricating oil flow to main bearings and crankshaft
7. Lubricating oil flow to front idler gears
8. Lubricating oil flow to piston cooling nozzles
9. Turbocharger oil supply tube
10. Turbocharger oil drain to crankcase.



07400269

1. Piston pin bushing
2. Connecting rod
3. Crankshaft.



1. Lubricating oil flow through cylinder head
2. Lubricating oil flow through rocker housing
3. Lubricating oil flow around rocker shaft capscrew and through rocker shaft
4. Lubricating oil flow through rocker levers
5. Lubricating oil flow through injector lever
6. Lubricating oil return to pan.