

Do you have Vehicle Cab (Bunk) Temperature or Thermostat Circuit (Aftermarket or OEM)	Go to 97-fc469aft (/qs3/pubsys2/xml/en/procedures/97/97-fc469aft.html)
Do you have Vehicle Cab (Bunk) Temperature or Thermostat Circuit (Integrated)	Go to 97-fc469int (/qs3/pubsys2/xml/en/procedures/97/97-fc469int.html)

Last Modified: 29-Sep-2004
