

Is the Engine Speed Sensor Circuit (with Variable Voltage Accelerator) used?	Go to 98-fc115vva (/qs3/pubsys2/xml/en/procedures/98/98-fc115vva.html)
Is the Engine Speed Sensor Circuit (with Frequency Accelerator) used?	Go to 98-fc115fa (/qs3/pubsys2/xml/en/procedures/98/98-fc115fa.html)

Last Modified: 27-Oct-2003
