



Installation Instruction

Installation Instruction Number: 4908436

Released Date: 11-mar-2015

Fuel Pump Short Block Service Kit Installation Instructions

Fuel Pump Short Block Service Kit Installation Instructions

Product Affected

- ISX15 CM2250
- ISX15 CM2250 SN
- ISX15 CM2350 X101
- QSX15 CM2250 ECF
- QSX15 CM2250 X115
- QSX15 CM2350 X105
- QSX15 CM2350 X106
- QSX15 CM2350 X118
- X15 CM2350 X114B

This document contains information for the use of a fuel pump short block service kit, Part Number 2872658PX.

Remove

Perform the following steps:

- Remove fuel pump.
 - See ISX15 CM2250 Service Manual, Bulletin 4022250. Refer to Procedure 005-016 in Section 5. (</qs3/pubsys2/xml/en/procedures/132/132-005-016-tr-mixar5.html>)
 - See ISX15 CM2350 X101 Service Manual, Bulletin 4310641. Refer to Procedure 005-016 (</qs3/pubsys2/xml/en/procedures/173/173-005-016-tr-prix13.html>) in Section 5.
 - For all other engines; see corresponding Service Manual. Reference Procedure 005-016 in Section 5.
- Remove fuel pump gear pump.
 - See ISX15 CM2250 Service Manual, Bulletin 4022250. Refer to Procedure 005-025 in Section 5.




(/qs3/pubsys2/xml/en/procedures/132/132-005-025-tr-mixar5.html)

- See ISX15 CM2350 X101 Service Manual, Bulletin 4310641. Refer to Procedure 005-025 (/qs3/pubsys2/xml/en/procedures/173/173-005-025-tr-prix13.html) in Section 5.
- For all other engines; see corresponding Service Manual. Reference Procedure 005-016 in Section 5.
- Remove fuel pump head.
 - See ISX15 CM2250 Service Manual, Bulletin 4022250. Refer to Procedure 005-227 (/qs3/pubsys2/xml/en/procedures/132/132-005-227-tr-mixar5.html) in Section 5.
 - See ISX15 CM2350 X101 Service Manual, Bulletin 4310641. Refer to Procedure 005-227 (/qs3/pubsys2/xml/en/procedures/173/173-005-227-tr-prix13.html) in Section 5.
 - For all other engines; see corresponding Service Manual. Reference Procedure 005-227 in Section 5.

Remove roller tappet guide pins and plugs.

Clean and inspect for reuse.



Install


Install new fuel pump tappets into new fuel pump short block.

Fuel pump tappet guide slot **must** face towards tappet guide pin bore.




Install fuel pump roller tappet guide pins.

Slot on rear of fuel pump guide pin **must** be vertical when installing fuel pump guide pin.



If necessary, use a small flat blade screw driver to verify correct fuel pump guide pin alignment to fuel pump tappet slot.

Figure at right shows correct fuel pump tappet guide pin alignment.



⚠ CAUTION ⚠

Verify correct fuel pump guide pin alignment after installing fuel pump guide pin plugs. Rotate fuel pump cam gear by hand. While rotating, both fuel pump tappets should move freely up and down in fuel pump bores. Damage to fuel pump will occur if fuel pump guide pins are installed incorrectly.



Install fuel pump guide pin plugs.

Torque Value:

1. 24 n•m [212 in-lb]

- Install fuel pump head.
 - See ISX15 CM2250 Service Manual, Bulletin 4022250. Refer to Procedure 005-227 (</qs3/pubsys2/xml/en/procedures/132/132-005-227-tr-mixar5.html>) in Section 5.
 - See ISX15 CM2350 X101 Service Manual, Bulletin 4310641. Refer to Procedure 005-227 (</qs3/pubsys2/xml/en/procedures/173/173-005-227-tr-prix13.html>) in Section 5.
 - For all other engines; see corresponding Service Manual. Reference Procedure 005-227 in Section 5.
- Install fuel pump gear pump.
 - See ISX15 CM2250 Service Manual, Bulletin 4022250. Refer to Procedure 005-025 in Section 5. (</qs3/pubsys2/xml/en/procedures/132/132-005-025-tr-mixar5.html>)
 - See ISX15 CM2350 X101 Service Manual, Bulletin 4310641. Refer to Procedure 005-025 (</qs3/pubsys2/xml/en/procedures/173/173-005-025-tr-prix13.html>) in Section 5.
 - For all other engines; see corresponding Service Manual. Reference Procedure 005-025 in Section 5.
- Install fuel pump.



- See ISX15 CM2250 Service Manual, Bulletin 4022250. Refer to Procedure 005-016 in Section 5. (/qs3/pubsys2/xml/en/procedures/132/132-005-016-tr-mixar5.html)
- See ISX15 CM2350 X101 Service Manual, Bulletin 4310641. Refer to Procedure 005-016 (/qs3/pubsys2/xml/en/procedures/173/173-005-016-tr-prix13.html) in Section 5.
- For all other engines; see corresponding Service Manual. Reference Procedure 005-016 in Section 5.

Document History

Date	Details
2015-3-11	Module Created
2017-5-24	Added Product Affected Section.

Last Modified: 07-Jun-2017
