



Installation Instruction

Installation Instruction Number: 4907711

Released Date: 12-jun-2007

Single Piece Piston Kit Installation Instruction

Single Piece Piston Kit Installation Instruction

Purpose

⚠ CAUTION ⚠

If the engine has not been completely upgraded to Monotherm™ pistons, replacing any fewer than all six (6) articulated pistons with Monotherm™ pistons could result in significant engine damage.

This kit contains one (1) Monotherm™ piston kit. It is important to note that articulated pistons are **not** compatible with Monotherm® pistons. Therefore, the engine can **only** operate with either all articulated pistons or all Monotherm™ pistons.

⚠ CAUTION ⚠

Failure to install connecting rods and rod bearings with an oil feed hole to Monotherm™ pistons could result in significant engine damage.

When upgrading to Monotherm™ pistons, connecting rods that are equipped with the oil drilling to the wrist pin bushing, along with drilled rod bearings **must** be used.

Refer to Procedure 001-043 (Pistons) in the Signature, ISX, and QSX15 Service Manual, Bulletin 3666239. (</qs3/pubsys2/xml/en/procedures/10/10-001-043.html>)